

Installation Procedures for Rigidized® Backsplash

The following information is provided to assist you in keeping your new backsplash looking its best for years to come.

Preparation

1. Make sure the surface on which you will place the backsplash is dry and free from debris and dust, as this impedes the adhesive bond strength.
2. We recommend a combination of Liquid Nails construction adhesive and two-sided tape for installation. Two-sided tape gives the panel immediate adhesive strength and the construction adhesive gives the panel a stable, solid bond.
3. Ensure that your backsplash panel is carefully lined up before installing your backsplash, as the two-sided tape will secure the backsplash immediately

Installation Instructions

Step One: Clean the surface on which you will place your backsplash, ensuring that it is free of dust, grease, loose paint or any other debris.

Step Two: Open and dispense Liquid Nails construction adhesive on the back side of the panel and spread it around.

Step Three: Peel off two-faced tape backers.

Step Four: Adhere the panel to the cleaned surface and push firmly to the wall.

Step Five: Peel the protective PVC tape off the front side of the panel. Be careful not to dent or scratch the front or back of the panel.

Step Six: Clean front side of panel with a stainless cleaner or mild soap.

Material Safety Data Sheets (MSDS) are available upon request.

